



Using standard "SuperGlue" (isocyanate) apply a 2" long line of the glue to the end of the pin that is to be reattached to the pole. As you insert the pin, rotate it back and forth to help distribute the glue. Stop inserting when you reach the halfway point. Lay the pole and pin down on a flat surface and allow it to dry for 15 minutes. You are now ready to use your AeroPole again.



1552 S. Anaheim Blvd #B Anaheim 92805 USA
714-991-8732 • www.AeroPoleSystem.com

How to repair an AeroPole with a loose connector pin